

RDS MFG, INC CROSSOVER TOOLBOX INSTALLATION

PLEASE READ ALL INSTRUCTIONS PRIOR TO INSTALLING THIS TOOLBOX! PARTS

Your RDS Crossover Toolbox Accessory & Installation Kit Consists of the Following:

- (1) Roll Soft Adhesive Backed Foam Tape
- (2) "J" Bolts With Nuts And Washers (All Crossovers Except Step/Sportside)



INSTALLATION

Step 1. - Cut soft foam tape into two equal pieces and with the help of another person, position toolbox onto truck rails, close to the cab. With the protective backing removed, place the foam strips between the toolbox and the truck rails, adhesive side to toolbox.

IMPORTANT - USING MORE THAN TWO SCREWS OR "J" BOLTS TO INSTALL THIS TOOLBOX MAY CAUSE METAL FATIGUE AND BOX FAILURE, AND INVALIDATES THE TOOLBOX WARRANTY.

Step 2. - STANDARD CROSSOVERS ONLY

With the toolbox in the desired position on the truck open lid to ensure clearance from cab window.

Next drill one 5/16" hole through toolbox (approx. 10 inches from front of box) be careful not to drill into the truck rail (leave 1/16" clearance between the hole and truck rail).

Install "J" bolts provided under truck rail and up through the hole in each end of the toolbox and tool keeper.

Tighten (do not over tighten) until foam strip is compressed to approx. 1/16".

Step 3. - STEP/SPORTSIDE CROSSOVERS ONLY

With the toolbox in the desired position on the truck, open the toolbox lid to ensure clearance from cab window, and drill a 1/8" hole through the toolbox and truck rail (approx. 10" from front of box), and install two (one on each end) 1/4" sheet metal screws (not included) through the toolbox into the truck rail. Tighten (do not over tighten) until foam strip is compressed to approx. 1/16".

Step 4. - Open, close & lock toolbox two or three times to ensure correct operation, adjust strikers & lubricate as necessary.

**WARNING – FAILURE TO FOLLOW THE ABOVE INSTRUCTIONS CAN AND WILL VOID WARRANTY.
FAILURE TO USE PROVIDED INSTALLATION KIT CAN AND WILL VOID WARRANTY.**

DANGER - Danger of **EXPLOSION**. Do not use this product for storing or transporting flammables, explosives, hazardous materials, or hazardous waste, such as containers of gasoline, solvents, gun powder, dynamite, propane tanks, acetylene tanks and cutting torches. This product is only intended and safe for use in storing and transporting small tools, equipment and other similar materials. Any modifications made to, or unintended use of this product, could create a hazardous condition that can cause death, serious personal injury or property damage.

CAUTION – RDS MFG, INC toolboxes are intended for the carrying of miscellaneous tools and/or equipment. Do not stand on or in the toolbox. Do not use the toolbox as a securing or anchor point. Do not use the toolbox to carry livestock or humans. Exercise caution when removing or placing objects in and out of the toolbox. Do not operate vehicle with an unsecured toolbox. Secure toolbox only with provided or approved fasteners.

CARE AND MAINTENANCE

1. Care for this toolbox as you do your vehicle with regular washing, using mild detergents and automotive polishes. CAUTION - do not use caustic, acidic or abrasive type cleaners or compounds.
2. Periodically wipe weather seal with light silicone protectant, such as Armor-all.
3. Periodically inspect lift cylinder shafts and wipe clean if necessary.
4. Frequently lubricate locks, latches and hinge mechanisms to assure smooth operation.

Following these instructions will get you the best possible service from your toolbox for years to come.

Limited Warranty

RDS Manufacturing Inc. warrants to purchasers that the products it sells are free from defects in materials and workmanship under normal use and service for a period of one year from date of purchase. This warranty does not cover defects or damage arising from improper installation, lack of proper maintenance, improper storage, shipping and handling, ordinary wear and tear, misuse, abuse, accident, unauthorized service, or use with or on unauthorized products or parts, or use for any other purpose than that stated herein. The only liability of the company hereunder in tort and contract, under this warranty shall be limited to the repair or replacement of any product or component part which shall prove defective to the original purchaser. RDS Manufacturing Inc. will not pay costs or repair performed other than in accordance with this warranty. Written notice of a product believed to be defective as covered by this warranty should be sent to: RDS Manufacturing Inc., 300 Industrial Park Dr., Perry, FL 32348, and should include the purchasers name and address, identification of the product, an original or copy of the receipt or invoice, and a brief description of the defect. Upon receipt of such notice the company will inform the purchaser where to Ship such product, shipping charges prepaid, for examination. In the event such examination reveals a defect covered by the Warranty, RDS Manufacturing Inc. will, at its own option, repair or replace the product and return it or the replacement to the purchaser, shipping charges prepaid. There are no express warranties except as listed above. The forgoing warranty is in lieu of any and all warranties, expressed or implied. All implied warranties, including but not limited to the warranties or merchantability and fitness for a particular purpose, are hereby excluded. RDS Manufacturing Inc., shall not be liable for incidental or consequential damages resulting from use of its products, or arising out of any breach of this warranty. The foregoing limitations and exclusions are intended to be effective to the maximum extent permitted by law.



RDS Manufacturing Inc.
300 Industrial Park Dr.
Perry, Florida 32348
(850) 584-6898